

Standard Head Installation Instructions

Step 1

Unwrap and separate Cavity, Head Piece and Closing Jamb.

Step 2

Attach Head Piece to the Cavity and the Closing Jamb and fix to studs.

Step 3

Align the Cavity to the wall line and fix through metal base plate.
* Note: Due to the variety of floor types, plate fixings are not supplied.

Step 4

Fix the hanger plate to the top of the door with the centre of the plate being 125mm from the doors edge.

Step 5

If you have requested a 'T' Guide, fix to floor and insert a groove 20mm deep and 5mm wide into the base of your door.

Step 6

Make sure that the door fits.

1. Insert the back hanger into the track
2. Slide along the Track
3. Insert the Front Hanger

4. Make sure the door moves freely and goes into the pocket.
* Note: At this time the door can be removed whilst the linings and finishing touches are made. Door can be refitted at a later time and the remaining steps can be completed.

Step 7

Adjust the Hangers so the door closes flush against the Closing Jamb without any gaps.

Step 8

Position the Pelmet and screw into place. Pelmet must be fitted before architraves. Do not fix architraves to pelmet.

Step 9

If using the standard Door Guide, fit to Split Jamb and adjust for smooth operation.

